


## Citroën C5\_AIRCROSS\_BEV


5 doors/ 5 seats/ SUV (2025/ -> )





t<sup>a</sup>ttt\*t






	Airbag		Stored gas inflator	Seat belt pretensioner	SRS control unit		
			Gas strut / Preloaded spring	High strength zone		4	High voltage component
000 000	Battery low voltage						
	Battery pack, high- voltage	N	High voltage power cable				
*******	Cable cut	<b>%</b>	Low voltage device that disconnects high voltage				

STELLANTIS	ID N°	Version N°	Version date	Page
	01365_25_00095	OR	10/07/2025	1/4


## 1. Identification / recognition



LACK OF ENGINE NOISE DOES NOT MEAN VEHICLE IS OFF, SILENT MOVEMENT OR INSTANT RESTART CAPABILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN. WEAR APROPRIATE PPE.



#### 2. Immobilisation / stabilisation / lifting




<u>∧</u>

Do not place cribbing such as wooden blocks or rescue air lifting bags under the fuel system or high voltage power cables. Doing so may result in fuel leaks, fire, or electric shock.

## 3. Disable direct hazards / safety regulations

#### Main disabling method




STELLANTIS	ID N°	Version N°	Version date	Page
31222	01365_25_00095	OR	10/07/2025	2/4


#### 4. Access to the occupants



#### High strength steel body



#### Seat adjustment



# Steering column adjustment



#### 5. Stored energy / liquids / gases / solids

000 000	12V	
Li-ion	400V	
**	0,9L	
4		



when coolant leaks from the battery pack, it can become unstable with risk of thermal runaway. Check battery pack temperature with thermal imaging camera.



#### 6. In case of fire



## Use large amount of water











Lithium-ion batteries may self-ignite or reignite once the fire has been extinguished. Monitor the temperature of the high-voltage battery!

STELLANTIS	ID N°	Version N°	Version date	Page
	01365_25_00095	OR	10/07/2025	3/4

## 7. In case of submersion



Remove the vehicle from the water then refer to chapter 3, Disable direct hazards / safety regulation


### 8. Towing / transportation / storage


#### **Location front hook**












STORE AT SAFE DISTANCE FROM OTHER VEHICLES!



## 9. Important additional information


















## 10. Explanation of pictograms used

	Remove smart key		Flammable
<u>^</u>	General warning sign		Hazardous to the human health
*	Warning; low temperature		Acute toxicity
4	Warning, Electricity		Explosive
**	Air-conditioning component		Corrosives
4	Electric Vehicle	( Solar	Use water to extinguish the fire
□\IR \\\\	Use thermal Infrared camera		Bonnet

STELLANTIS	ID N°	Version N°	Version date	Page
31222,4113	01365_25_00095	OR	10/07/2025	4/4