









	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
			Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage								
			Low voltage device that disconnects high voltage		Fuel tank content gasoline/ethanol				

1. Identification / recognition



Model name




Brand logo

2. Immobilisation / stabilisation / lifting

Immobility






Stabilization/lifting points



Do not place cribbing such as wooden blocks or rescue air lifting bags under the fuel system or high voltage power cables. Doing so may result in fuel leaks, fire, or electric shock.

3. Disable direct hazards / safety regulations

Main disabling method




4. Access to the occupants

Door latches




Glass types





5. Stored energy / liquids / gases / solids

	12V	  
	60L	 

8. Towing / transportation / storage



9. Important additional information



10. Explanation of pictograms used

	Remove smart key		Flammable
	General warning sign		Hazardous to the human health
	Bonnet		Explosive
	Vehicle on fuel of liquid group 1		Corrosive