




DACIA SPRING

(2021 -)



	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage		Ultra-capacitor, low-voltage		Fuel tank		Gas tank		Safety valve
	Battery pack, high-voltage		High voltage power cable		High voltage device that disconnects high voltage		Fuse box disabling high voltage		High voltage ultra-capacitor

Internal reference

Version date

Version

Page

RS-BBG-2021-1

02/09/2021

1

1 / 4


1. Identification / recognition




2. Immobilisation / stabilisation / lifting

Immobilisation

Engine shutdown




Forbidden wedge area




Orange 230V cables area

3. Disable direct hazards / safety regulations

12 Volts Battery



- 1 - Engine shutdown
- 2 - Disconnect the negative terminal (-)



400 Volts battery





Only if cutting operation is necessary :

Disconnection of the 230 Volts battery by removing the service plug.



4. Access to the occupants

HARDENED STEEL






5. Stored energy / liquids / gases / solids


	Lithium-ion	27,4 kW.h	230 V
--	-------------	-----------	-------



6. In case of fire

Extinguishing a traction battery fire propagation











If traction battery on fire : → Water extinguishing by filling

TAILGATE GAS STRUTS



Risk of missile effect of tailgate gas struts

7. In case of submersion











No electrical hazard

8. Towing / transportation / storage



10. Explanation of pictograms used

 Electric Vehicle			 Bonnet	
 Use thermal Infrared camera			 Special battery access	
Electrical protection gloves 	Face shield 	Breathing apparatus (BA) 	Use water to extinguish the fire 	Don't brake, nor open 