	WEY SUV From 1	COFF I	EE 02		- F		
			STAP S				
		4 y		9.			
_egend		Li-ion I 309	Battery 12 V				
	-		Stored gas	Seat belt pre-	SRS control	0 00	Battery low
	Airbag Gas strut/ Preloaded spring		inflator High strength zone	tensioner Zone requiring special atten- tion	 unit High voltage battery pack	5	voltage High voltage power cable/
	Gas strut/		inflator High strength	Zone requiring special atten-	High voltage	5	voltage High voltage

WEY COFFEE 02 SUV

From 11/2022



1. Identification / recognition



LACK OF ENGINE NOISE DOES NOT MEAN VEHICLE IS OFF. SILENT MOVEMENT OR INSTANT RESTART CAPA-BILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN. WEAR APPROPRIATE PPE.






2. Immobilisation / stabilisation / lifting


Immobilise and stabilise the vehicle







Lifting points





• Apply parking brake;

- Press "P" button;
- Shut power off.

3. Disable direct hazards / safety regulations

MAIN DISABLING METHOD





This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.
	LGW-WEY-V61PHEVG	V1	2/4


From 11/2022

4. Access to the occupants

WHEN THE 12 V BATTERY IS DISCONNECTED, ELECTRICAL COMPONENTS CANNOT BE OPERATED.

<u>High strength zone</u>


Seat adjustment



Steering column adjustment Glass types



5. Stored energy / liquids / gases / solids



6. In case of fire



7. In case of submersion

Proper personal protective equipment should be worn when handling any flooded vehicle. Pull the vehicle out of water as much as possible, immobilise the vehicle and disable the vehicle before starting any operation (see chapter 3).

This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.
	LGW-WEY-V61PHEVG	V1	3/4



Tilt the vehicle to one side to allow water to drain out of the vehicle.

8. Towing / transportation / storage

Location front hook

Location rear hook









STORE AT SAFE DISTANCE FROM OTHER VEHICLES !



9. Important additional information



Driver's seat has a far side airbag in addition to the side airbag. Location of far side airbag is shown in the mark 9. on page 1.

10. Explanation of pictograms used

Pictogram	Designation	Pictogram	Designation	Pictogram	Designation
R	Low voltage device that disconnects high volt- age		Flammable		Hazardous to the human health
	Remove smart key		Explosive		Use water to extinguish the fire
	Boot	and the second sec	Corrosives	4	Warning, Electricity
	Bonnet		Use thermal Infrared camera		General warning sign
₩	Air-conditioning compo- nent				

This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.
	LGW-WEY-V61PHEVG	V1	4/4