





Audi Q4 e-tron

SUV / Sportback, as of 2021

5-door, 5-seater



400 V
LI-ION



	Airbag		Stored gas inflator		Belt tensioner		SRS control unit		Gas strut / Preloaded spring
	High strength zones		Battery pack, low voltage		Battery pack, high-voltage		High voltage power cable		Low voltage device that disconnects high voltage
	Fuse box disabling high voltage		High voltage component		Cable cut				



Audi Q4 e-tron

SUV / Sportback, as of 2021

5-door, 5-seater

1. Identification / recognition



The electric drive motor is silent. The display in the instrument cluster (power meter) provides feedback as to whether the electric drive is switched to OFF, or READY for operation.

Q4 lettering
(lettering can be deselected)

e-tron lettering



Vehicle charging socket

SUV



Sportback




2. Immobilisation / stabilisation / lifting

Immobilising the vehicle



1 Press park button "P"

Lifting points



Appropriate lifting points


High-voltage battery

3. Disable direct hazards / safety regulations

Switching off the ignition



1 Switch off ignition (power meter "OFF"), press "Start-Stop" button without operating foot brake.



Remove vehicle key, key card and/or smartphone app so that they are more than 5 m away from the vehicle if possible.


Deactivating the high-voltage system

In the event of an accident in which the airbag is triggered, the high voltage system is automatically deactivated when airbag triggering is detected. The high voltage system is de-energised approx. 20 seconds after deactivation.



In all other cases, the high voltage system can be deactivated as follows:

Option 1: in the vehicle front end



- 1 Locate emergency cut-out connection
- 2 Actuate emergency cut-out connection



1 Pull out the red tab



2 Pull out the black connector





Audi Q4 e-tron


SUV / Sportback, as of 2021

5-door, 5-seater




Option 2: fuse in the passenger compartment



Left-hand drive vehicles
(next to steering column)
Remove cover



Right-hand drive vehicles
(in the glove compartment)
Remove cover





Pull out the fuse



Option 3: cutting point in luggage compartment on rear cross panel

Remove luggage com-
partment floor

Cut the cable at the yellow label



Do not touch, cut or open damaged high voltage components, cables and high voltage batteries! Wear appropriate personal protective equipment!


Disconnecting the 12-volt vehicle battery (in the engine compartment)



Disconnect the negative terminal (for battery position, see graphic on page 1)





Disconnecting from the charging station (manual release of charging connector)




Remove luggage com-
partment floor

Pull the yellow loop

Disconnect the charging
connector



4. Access to the occupants



Glass types:

- 1 Laminated glass
- 2 Tempered glass
- 3 Optional side windows
Laminated glass

5. Stored energy / liquids / gases / solids



12 V



Audi Q4 e-tron

SUV / Sportback, as of 2021

5-door, 5-seater



400 V
Lithium-ion



In the event of mechanical deformation of the battery system, there is a risk of a thermal reaction in the high voltage battery.
Monitor the temperature of the high-voltage battery!



6. In case of fire



Lithium-ion batteries can self-ignite either immediately or after a delay when damage occurs or they are not used properly, or re-ignite after fire-fighting measures.
Wear appropriate personal protective equipment!



7. In case of submersion

After recovering the vehicle from the water, deactivate the high voltage system and 12 V electrical system (see section 3) and allow the water to drain. Wear appropriate personal protective equipment!

8. Towing / transportation / storage



Lithium-ion batteries can self-ignite or re-ignite after fire-fighting measures!



In the event that vehicles that have been in accidents have a damaged battery or the battery exhibits anomalies: disable the high voltage system (see section 3). Park the vehicle at a safe distance of at least 5 metres from buildings and other vehicles (quarantine area).



A vehicle that has been in an accident must not be towed on its drive axles.



9. Important additional information

Further information can be found in the Audi guideline for rescue services at www.audi.com/rescue

10. Explanation of pictograms used



Flammable



Corrosive,
skin irritant



Hazardous to
human health



Environmental
hazard



Gases under
pressure



Electric vehicle



Warning
High voltage




General
warning sign



Use water to
extinguish the
fire



Dangerous
voltage




Remove smart
key



Use thermal
Infrared camera



Unlock bonnet



Unlock boot