


Electric Vehicle model 5 doors / 5 seats From 2025










【2WD(49kwh) 】 305.3V Li-ion

【2WD(61kwh)&4WD 】 381.6V

Li-ion



	Airbag		Stored gas inflator			Seat belt pretensioner		SI	RS control unit			Gas strut/ Preloaded spring
	High strength zone	0 000	Battery low voltage	0		Battery pack, high-voltage	7		gh voltage ower cable	4		High voltage component
<u>//</u>	Low voltage device that disconnects high voltage	HH	Ultra capacitor, low voltage	X <sup>®</sup> -X	* * * * * * * * * * * * * * * * * * *	Cable cut						
	ID No.		No.	Version No	).	Version da	te	Pa	age			

A8I049/A8I061

01

2025

1/5



Electric Vehicle model 5 doors / 5 seats From 2025

### 1. Identification / Recognition

Location of vehicle badges

Lack of engine noise does not mean vehicle is off: silent movement or instant restart capability exists until vehicle is fully shut down wear appropriate ppe.





The model name and the SUZUKI emblem are on the tailgate

### 2. Immobilisation / Stabilisation / Lifting


- Immobilise the vehicle
- Chock the wheels and engage the parking brake.



- 1. Set ignition "ON".
- Press the P position switch.



Lifting points



- Floor jack position
- Position of center of gravity without load in vehicle
- Support position for frame contact hoist and safety stand



Do not place supports such as wooden blocks or life pillows under the exhaust system, fuel system, or high-voltage cables. Doing so can cause fuel leakage, fire, or electric shock.

# 3. Disable Direct Hazards / Safety Regulations

• If any of the following systems are required to be operated, operate them BEFORE disconnecting the battery.

Power door lock Power window Back door

When the 12 V battery is disconnected, electrical components cannot be operated.

If the charging cable is connected to the vehicle, please disconnect the charging connector.

ID No.	Version No.	Version date	Page
A8I049/A8I061	01	2025	2/5



Electric Vehicle model 5 doors / 5 seats From 2025

#### Main disabling method





Set ignition "OFF".



Move 20 feet away from the vehicle.



Disconnect negative (–) cable at battery.

# Alternative disabling method 1










Open the tailgate and Remove quarter lower trim cap.



Slide the lock toward arrow 1, then pull the service plug toward arrow 2.



Disconnect negative (–) cable at battery.

### Alternative disabling method 2


#### NOTE

Cut the labelled cables(1) in either the motor compartment or the luggage compartment.









# Luggage compartment







#### Access to 12 V Battery









Disconnect negative (–) cable at battery.

ID No.	Version No.	Version date	Page	
A8I049/A8I061	01	2025	3 / 5	



Electric Vehicle model 5 doors / 5 seats From 2025

# 4. Access to the Occupants

#### Glass types


Laminated





### Tempered

# Steering column adjustment



### Manual seat adjustment







## Power seat adjustment







# 5. Stored Energy / Liquids / Gases / Solids













12V

305.3V 2WD(49kwh) 381.6V 2WD(61kwh),4WD







HFO-1234yf 570 - 630g

> HFC-134a 650 - 710 g

### 6. In Case of Fire



For first-aid fire extinguishing, pour enough water from fire hydrant etc. Plenty of water may cool the system.











Use a thermal imaging camera to detect an increase in temperature at the high-voltage components



Lithium-ion batteries can self-ignite or re-ignite after fire-fighting measures!

ID No.	Version No.	Version date	Page
A8I049/A8I061	01	2025	4/5



Electric Vehicle model 5 doors / 5 seats From 2025

### 7. In Case of Submersion



Work on the vehicle only after the vehicle has been pulled out of the water.

# 8. Towing / Transportation / Storage



















Lithium-ion batteries can self-ignite or re-ignite after fire-fighting measures!

Store the vehicle at a safe distance (15 m (49.2 ft) or more) from other vehicles.



High-voltage battery: there is a possibility of re-ignition!

# 9. Important Additional Information

For further details, please refer to "Emergency Response Guide".

### 10. Explanation of Pictograms Used

<u>^</u>	General warning sign	<b>(3)</b>	Flammable		Remove smart key
4	Warning, Electricity		Corrosives		Bonnet
1	Electric Vehicle		Explosive		Boot
*	Air-conditioning	<b>\$</b>	Hazardous to the human health	☐ IR ∭	Use thermal Infrared camera
	Use water to extinguish		Acute toxicity		

ID No.	Version No.	Version date	Page	
A8I049/A8I061	01	2025	5 / 5	